

## REGUPOL PLAYFIX INDOOR SAFETY FLOORING

Please make sure to carry out the repair work as follows:

Remove protruding rubber and coating residues with a carpet knife. Then finish these areas with sandpaper. Dust and dirt residues must be vacuumed off. Next, apply the single component **REGUPOL adhesive 40-201** to the damaged areas and level it out using a moist spatula. Then leave the mixture to dry for approx. three to four hours until the skin has set.

In the event of major damage, the compound may sag slightly. Repeat the first process again to achieve a better result.

Next, the coloured finish is prepared. Mix the A and B components in the ratio indicated of approx. 6:1 (5.67:1) (usage: approx. 0.15 kg / m<sup>2</sup>) and apply it with a small lamb's wool roller or a brush. Drying time is around 8 hours.

Once mixed together, these components react and must be used very quickly. You should therefore try to mix the precise amount of coloured finish you require. Make sure the opened container is closed again carefully.

More serious damage should be repaired by **REGUPOL** specialists.

### Composition:

- **REGUPOL adhesive 40-201** (3 cartridges of 310 ml each)
- 1 kg **REGUPOL PUR 21-303 A + B**,  
A component (0.85 kg), B component (0.15 kg),  
A-and B components approx. 6 : 1 (5.67 : 1),  
sufficient for approx. 6 m<sup>2</sup>

